



New Generation of Appliance



کتری برقی

مدل: NL-2934

فارسی ☐

English ☐

مقدمه

لطفاً پیش از استفاده از کتری برقی، این دستورالعمل را مطالعه کنید. این دستورالعمل را برای ارجاعات بعدی نگهدارید.

ویژگی های محصول

۱. جوش آمدن سریع؛
۲. خاموش شدن خودکار در هنگام به جوش آمدن آب؛
۳. دستگاه با محافظت در برابر جوش خشک؛
۴. چرخش ۳۶۰ درجه؛
۵. با صیقل کاری بیرونی زیبا؛
۶. گرم نگه داشتن آب.

پیش از استفاده از این راهنما

۱. اطمینان حاصل کنید وقتی محصول با بسته بندی مناسب به دست شما می رسد.
۲. لطفاً مقادیر درج شده را بررسی کنید تا اطمینان حاصل کنید که با منبع برق محلی شما مطابقت داشته باشد.
۳. بدنه را روی پایه قرار دهید، سپس این محصول می تواند کار کند.
۴. پیش از اولین استفاده باید تمیز شود.
۵. وقتی آب به جوش آمد، مستقیماً آب را ننوشید. ابتدا آب را داخل ظرفی دیگر بریزید.
۶. آب را تا بالای خط ماکسیمم نریزید.
۷. آبی را که مدت زیادی مانده نجوشانید. آب را برای یک زندگی سالم عوض کنید.

روش استفاده

۱. پیش از روشن کردن برق، لطفاً آب را در جایی دور از برق اضافه کنید.

۲. لطفا میزان آب را مطابق با خطوط کمینه (MIN) و بیشینه (MAX) اضافه کنید. این میزان نباید کمتر از خط MIN باشد، در غیر اینصورت دستگاه به درستی کار نخواهد کرد. این میزان نباید بیشتر از خط MAX باشد. در غیر اینصورت در هنگام به جوش آمدن، سر ریز خواهد شد.
۳. پس از پر کردن آب، لطفا درب را ببندید.
۴. اطمینان حاصل کنید پایه دستگاه روی محلی مناسب نگهدارنده قرار گیرد و تمام شرایط ایمن باشند.
۵. در هنگامی که کتری در حال کار است، چراغ نشانگر روشن می‌شود. و در هنگامی که آب به جوش آمد، چراغ نشانگر بصورت خودکار خاموش خواهد شد. لطفا این مسئله را بررسی کنید و اگر به این شکل کار نمی‌کند، با مرکز خدمات مشتریان تماس بگیرید.
۶. اگر کاربر قصد دارد کتری در حال کار را متوقف سازد، تنها کافیست روی سوئیچ فشار داده تا پایین برود.
۷. این کتری عملکرد گرم نگاه داشتن را دارد، و حرارت آن تا یک دمای مشخص کاهش می‌یابد و آب در تمام مدت پس از جوش آمدن در این دما باقی خواهد ماند.

مشخصات

مدل	NL-2934
ولتاژ درج شده	۲۲۰-۲۴۰ V
وات درج شده	۱۵۰۰-۱۸۰۰ W
فرکانس	۵۰/۶۰ Hz

اقدامات عمومی ایمنی

نکته

۱. این دستگاه تنها برای مصرف خانگی مناسب است.
۲. پیش از استفاده از این دستگاه، در منبع برق باید اتصال به زمین آن چک شود.
۳. پیش از استفاده، لطفاً اطمینان حاصل کنید که اطلاعات مربوط به منبع برق $V - 220 - 240$ Hz، $50/60$ درج شده رو دستگاه با منبع برق محلی یکسان باشد.
۴. لطفاً از دستگاه تحت شرایطی استفاده کنید که ولتاژ درج شده به میزان 10% کمتر از خروجی حقیقی نباشد.
۵. اگر کابل برق محصول آسیب دیده است، کاربر باید برای تعویض آن با کارخانه تماس بگیرد.
۶. لطفاً در هنگام پر کردن کتری، آن را از پایه دور کنید. در هنگام جوشاندن آب، پایه کتری را خشک نگه دارید.
۷. کاربر نباید در هنگامی که کتری در حال جوش آوردن آب است محل را ترک کند.
۸. این دستگاه را دور از دسترس کودکان نگاه دارید تا از آسیب به آنان جلوگیری شود.
۹. لطفاً این دستگاه را جدا از دیگر محصولات برقی خود نگه داری کنید.
۱۰. در هنگامی که کاربر دستگاه را روشن می‌کند، درب باید بسته شده باشد و افراد باید دور از آن باشند. در هنگام کارکرد و پس از به جوش آمدن آب، بدنه کتری را لمس نکنید.
۱۱. آب و دیگر مایعات را تنها درون بدنه کتری بریزید، آب را روی کابل برق، دوشاخه و پایه نریزید.
۱۲. لطفاً کابل برق را نزدیک اشیاء داغ قرار ندهید.
۱۳. در هنگامی که آبی درون کتری نیست، برق آن را متصل نکنید؛ در هنگام تمیزکاری یا وقتی شخصی با آن کار می‌کند، دستگاه را روشن نکنید.

۱۴. این محصول برای به جوش آوردن آب است. لطفاً دیگر مایعات شیمیایی را درون آن نریزید در غیر اینصورت منجر به آسیب خواهد شد.

۱۵. اگر کتری برقی کار نمی‌کند، لطفاً آن را برای تعمیر به مراکز معتبر ارسال کنید.

۱۶. هر یک از این دستگاه‌ها، پایه خود را دارند، از این محصول روی یک پایه دیگر استفاده نکنید. در صورت عدم اطمینان از دیگر قطعات یدک استفاده نکنید.

- هشدار برای اجتناب از ترشح آب روی رابط برق.
- جزئیات در مورد چگونگی تمیزکاری سطحی که با مواد غذایی در تماس است.
- هشدار در مورد آسیب بالقوه در صورت استفاده ناصحیح.
- توضیح اینکه سطح المنت حرارتی پس از استفاده همچنان در معرض گرمای باقیمانده قرار دارد و داغ است.

۱۷. کودکان از سن ۸ سال به بالا در صورتی که بر آنها نظارت شود یا دستورالعمل مربوط به استفاده از دستگاه به طریقی ایمن به آنها آموزش داده شود و در صورتی که خطرات موجود را درک کنند، می‌توانند از دستگاه استفاده کنند.

۱۸. تمیزکاری و نگهداری نباید توسط کودکان صورت گیرد مگر آنکه بیش از ۸ سال سن داشته باشند و بر آنها نظارت صورت گیرد.

۱۹. دستگاه و کابل آن را دور از دسترس کودکان با سن کمتر از ۸ سال نگه دارید.

۲۰. روی کودکان باید نظارت صورت گیرد تا با دستگاه بازی نکنند.

۲۱. دستگاه‌ها معمولاً پس از استفاده تمیز می‌شوند و نباید آنها را برای تمیزکاری در آب غوطه ور ساخت، چرا که این دستگاه مناسب قرار گیری درون آب نیست.

نگهداری و تمیزکاری

تمیزکاری

- همواره پیش از تمیز کاری دوشاخه را از منبع اصلی برق جدا کنید!

- بدنه خارجی دستگاه در صورت نیاز باید با یک پارچه اندکی مرطوب بدون هیچ افزودنی تمیز شود.
- هرگز مواد شوینده را دورن کتری نریزید. این کار ممکن است کارکرد را ناامن کرده و به دستگاه آسیب بزنند.

جرم زدایی

- کتری باید بصورت مرتب جرم زدایی شود.
- برای تمیزکاری از یک تمیز کننده مخصوص جرم استفاده کنید.
- پس از آن کتری را با آب تمیز بشوید.

این نماد نشان می‌دهد که در سراسر کشور این محصول نباید با دیگر زباله‌های خانگی دور ریخته شود. لطفاً دستگاه را برای پرهیز از آسیب محتمل به محیط زیست و سلامت انسان در برابر دفع کنترل نشده زباله، بازیافت کنید تا بتوان از این منبع دوباره استفاده کرد. برای عودت دستگاه مستعمل، لطفاً از سیستم‌های جمع‌آوری و برگشت استفاده کرده یا با خرده‌فروشی که دستگاه از آن خریداری شده تماس حاصل فرمایید تا دستگاه را تحویل بگیرند.



Please read this instruction before using this electric kettle. Keep this manual for daily reference.

PRODUCT FEATURES

1. Fast boiling;2.Automatic power off when water boiled;3.With dry boil protection device;4.360 degree rotation;5. With beautiful outside finish; 6. Keep warm.

BEFORE USING THE GUIDELINES

1.Confirm the package is good when get this product. 2. Please check the rating to confirm if it is same with local power supply.3. Put body on the base then this product can work. 4. It need to be cleaned before first using. 5. When water boiled, do not drink water directly. Pour water out first. 6. Do not put water above maximum line. 7. Do not boil long-term water, should change water for healthy life.

METHOD OF USE

1. Before turn on power, please add water at the place disconnect with power.
2. Please add water according to MIN-line and MAX-line. No less than MIN, or it will not work properly. No more than MAX or hot water will overflow when boiled.
3. After filling water, please cover the lid.
4. Confirm the base is on the appropriate supporting place and it is connecting with power supply. Confirm kettle is rightly on the base and all the condition is safe.
5. When the kettle is working, the indication light begins lighted. And when the water boiled, the indication light will be automatically off. Please check this and if it does not work like this, contact with customer service center.
6. If user want to stop the working kettle, just press the switch to turn down.
7. The kettle has keep warm function, it will drop to a certain insulation temperature and remain at this temperature all the time after boiling.

SPECIFICATIONS

Model	NL-2934
Rated Voltage	220-240V
Rated Wattage	1500-1800W
Frequency	50/60Hz

GENERAL SAFETY PRECAUTIONS

1. This product is only for household use.
2. Before using this product, grounding device need to be checked on the power.
3. Before using this product, please confirm the power supply 220-240v 50/60Hz is same with local powersupply.
4. Please use the product under the situation that the voltage on the rating is no less than 0% of the true outlet.
5. If the products power cord is damage, user should contact factory to replace it.
6. Please move away the base of kettle when enter water. Keep kettle base dry when boiling water.
7. User should not be absent when the kettle is boiling water.
8. Keep this product away from children to avoid do harm to them.
9. Please put this product away from other electronic product.
10. When user turns on this product, the lid should be covered and people should be away from it. **DO NOT TOUCH ITS BODY** when it is working and afer water boiled.
11. Only put water or other liquid inside kettle body, do not put water on power cord, plug and base.
12. Please do not put power cord near heating subject.
13. Do not turn on the power when no water inside kettle; do not turn on when it is being cleaning or anyone who is operating.
14. This product is for water boiling. Please do not put other chemical liquid in it or it will lead to damage.
15. If the electric kettle does not work, please send back to authorized center to repairs. Do not repairs it by own.
16. Every of this product has its own base, do not use this product by other base. Do not use other spare parts when not confirm.

- A warning to avoid spillage on the connector.
- Details on how to clean the surfaces in contact with food.
- A warning of potential injury from misuse.
- A statement that the heating element surface is subject to residual heat after use.

17. This appliance can be used by children aged from 8 years and above if they have been given supervision or instruction concerning use of the appliance in a safe way and if they understand the hazards involved.

18. Cleaning and user maintenance shall not be made by children unless they are older than 8 and supervised.

19. Keep the appliance and its cord out of reach of children aged less than 8 years.

20. Children being supervised not to play with the appliance.

21. Appliances normally cleaned after use and not intended to be immersed in water for cleaning. State that the appliance must not be immersed.

CARE AND CLEANING

Cleaning

- Always remove the plug from the mains supply before cleaning the appliance!
- The exterior of the machine should be cleaned, if necessary, with a slightly damp cloth without additives.
- Never put cleaning detergents into the kettle. This will make the operation unsafe and damage the unit.

Descaling

- Kettle should be descaled regular.
- For cleaning, use a special cleaner from scale.
- After that wash the kettle with clean water.



This marking indicates that this product should not be disposed with other household wastes throughout the nation. To prevent possible environmental or human health harm from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmentally safe recycling.



QUALITY EXPERIENCE



Electric Kettle
Model: NL-2934

فارسی ☐
English ☐