



NEW LAND

New Generation of Appliances



کنتری برقی
درجہ گردان ۳۶۰
مدل: NL-2729



**360 Degree Rotation
Automatic Cordless Kettle
Model: NL-2729**


دستورالعمل‌های اینتی عمومی

اسعافی ۷ هزار دانشجوی اسلامیه سواد ابتدی افراد بحث هنرها بررسی

Tragö


یا دستورالعمل استفاده از دستگاه را در حالت اینمن و خطرات ممکن با این

E slightly damp cloth without additives. The calcium filter can be removed for cleaning. Power Supply AC 220-240V 50-60Hz 1350-1600W.



تہذیب کا

همینه قفل از تمیز کردن کنتری آن را برق خارج کند. قسمت خارجی
کنتری باید تمیز شود. اگر ضروری است با یک پارچه نمودار بدون مواد اشکافه
این کل را انجام دهد. فیلتر چدایکنده گلکسیم می تواند برای تمیز کردن



General Safety Instructions

- Before using this kettle, please read the instruction manual carefully.
 - Please keep the instruction manual, guarantee certificate, the sales receipt and if possible, the carton with the inner packaging. This kettle is intended exclusively for private and not for commercial use.
 - Switch off the kettle and remove the plug from the socket when cleaning or when you disconnect the power cord of the kettle, grasp and pull the plug, not the cord!
 - Switch off the kettle before cleaning the kettle.
 - Do not leave the kettle unattended by children. Do not leave children unsupervised with the kettle.
 - This appliance can be used by children aged from 8 years and up and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and if they understand what is expected of them. Cleaning and user maintenance shall not be carried out by children unless supervised. Keep the appliance and its cords out of reach of children and pets.
 - Appliances can be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and if understand the hazards involved.
 - Always use the kettle with the appliance.
 - Test the kettle and the cord/cable regularly for damage. Check that the kettle is operating properly. If there is damage of any kind or if the kettle does not operate correctly, stop using the kettle and unplug it immediately.
 - Do not attempt to repair the kettle yourself; only authorized and qualified persons may repair this kettle.